

# Interface Range Command

# Table of Contents

Chapter 1 Interface range command..... 1  
    1.1 interface range..... 1

# Chapter 1 Interface Range Command

## 1.1 Interface Range

### Description

**interface range** *type slot* <*port1 - port2* | *port3*> [<*port1 - port2* | *port3*>]

### Parameter

Name	Description	Description
<i>type</i>	Interface type	All legal interface types except for the management interface on the main control board of the rack-mounted switch.
<i>slot</i>	Slot number	All legal slot numbers
<i>port1</i>	Beginning value of the port number	All legal port numbers on the slot.
<i>port2</i>	Ending value of the port number	All legal port numbers on the slot except for port 1.
<i>port3</i>	A single port.	All legal port numbers on the slot.

### Default

none

### Instruction

Use this command to enter the interface range mode.

### Example

Use the following command to enter the interface configuration mode, including slot 0 and fast Ethernet port 1,2,3,6,8,10,11,12:

```
switch_config#interface range 1 - 3 , 6 , 8 , 10 - 12
switch_config_if_range#
```