

## MAC Address List Characteristic Configuration Commands

---

# Table of Contents

Chapter 1 MAC Access List Configuration Commands .....	1
1.1 MAC Access List Configuration Commands.....	1
1.1.1 mac access-list.....	1
1.1.2 permit .....	1
1.1.3 deny.....	2
1.1.4 mac access-group.....	3

# Chapter 1 MAC Access List Configuration Commands

## 1.1 MAC Access List Configuration Commands

- mac access-list
- permit
- deny
- mac access-group

### 1.1.1 mac access-list

#### description

To add a MAC access list, use the mac access-list command. To delete a MAC access list, use the mac access-list command.

**[no] mac access-list** *name*

#### parameter

parameter	Description
<i>name</i>	MAC access list name.

#### default

none

#### command mode

Global configuration mode

#### example

The following example establishes MAC access list named mac-acl:

```
Switch-config_# mac access-list mac-acl  
Switch-config-macl#
```

### 1.1.2 permit

#### description

To add a permit entry to the MAC access list, use the permit command. Use the no form of this command to delete a permit entry from the MAC access list.

**[no] permit** {**any** | **host** *src-mac-addr*} {**any** | **host** *dst-mac-addr*}[*ethertype*]

### parameter

parameter	description	Value range
any	Any value	—
host	Host	—
src-mac-addr	Source MAC address	H.H.H
dst-mac-addr	Destination MAC address	H.H.H
<i>ethertype</i>	Types of the matching ethernet data packet.	0-0xFFFF

### default

deny all

### command mode

MAC access list configuration mode

### example

The following example permits host whose source MAC address is 1234.5678.abcd:

```
Switch-config-macl#permit host 1234.5678.abcd any 0x806
```

### 1.1.3 deny

### description

To add a deny entry to the MAC access list, use the deny command. Use the no form of this command to delete a deny entry from the MAC access list.

**[no] deny {any | host *src-mac-addr*} {any | host *dst-mac-addr*}[*ethertype*]**

### parameter

parameter	Description	Value range
any	Any value	—
host	Host	—
src-mac-addr	Source MAC address	H.H.H
dst-mac-addr	Destination MAC address	H.H.H
<i>ethertype</i>	Types of the matching ethernet data packet.	0-0xFFFF

### default

deny all

**comamnd mode**

MAC access list configuration mode

**example**

The following example denies host whose source MAC address is 1234.5678.abcd:

Switch-config-macl#deny host 1234.5678.abcd any 0x806

**1.1.4 mac access-group****description**

To apply the configured MAC access list in global configuration mode, use the mac access-group command. Use the no form of this comand to delete the mac access-list.

**[no] mac access-group** *name*

**parameter**

parameter	Description
<i>name</i>	Name of the MAC access list.

**default**

No MAC access list is applied.

**Command mode**

Global configuration mode

**example**

The following example configures MAC access list named macacl:

Switch\_config#mac access-group macacl